

XX.Y®

Adapter Bluetooth audio transmitter receiver

User manual



TR01

Before use

About THE BT TRANSCEIVER

THE BT TRANSCEIVER is a Bluetooth transmitter and receiver. When it is used as a Bluetooth transmitter, it can be connected to your MP3 player or laptop without Bluetooth function to wirelessly transmit music to your Bluetooth receiver (such as Bluetooth stereo headset, Bluetooth stereo speaker and so on). When it is used as a Bluetooth receiver, it can be connected to your common audio devices (such as Bluetooth cell phone, Bluetooth transmitter) for wireless music playing.

1. Device operation description

a) When THE BT TRANSCEIVER is used as a Bluetooth transmitter, you need to prepare an audio player with 3.5mm audio-out jack and a Bluetooth A2DP receiver, such as Bluetooth stereo headset, Bluetooth stereo speaker and so on.

b) When THE BT TRANSCEIVER is used as a Bluetooth receiver, you need to prepare a stereo receiver with 3.5mm audio-in jack and a Bluetooth A2DP transmitter, such as Bluetooth cell phone, Bluetooth MP3 and so on.

2. Device description

1. Multi-function button: switching on/off, pairing
2. LED indicator of transmitter mode
3. LED indicator of receiver mode
4. LED indicator of working/charging
5. Port 3.5mm, transmitter mode
6. Micro USB charging port
7. Port 3.5mm, receiver mode
8. 2 X mini jack 3.5mm cable
9. 2 X RCA - mini jack 3.5mm cable
10. Charging cable micro USB - USB



3. Turning on/off

- 1) To turn on the adapter keep pressing multifunction button for 4-5 second
- 2) To turn off the adapter keep pressing multifunction button for 4-5 second

4. Charging the battery

TR01 has li-po battery built in. It is recommended to charge the battery fully before first use.

The flashing red LED show low power. To charge the battery plug one end of charging cable into USB port and the other into micro USB port on the adapter. During charging red LED light is on. It takes about 2 hours to charge the adapter fully. After the battery is charged the red LED light is goes out.

Charging the battery during work

It is possible to charge battery while it is working.

5. Transmitting mode

Pairing with a Bluetooth device (receiver).

After connecting transmitter to a Bluetooth stereo receiver, you can enjoy music wirelessly. Before pairing, please make sure your Bluetooth stereo receiver supports Bluetooth A2DP profile.

The pairing steps are as follows:

- 1) Keep the transmitter and your Bluetooth stereo receiver within 1 meter;
- 2) To switch to transmitting mode put 3.5mm plug in green 3.5mm port on the adapter.
- 3) Press and hold multifunction button of the transmitter for 4-5 seconds and do not release it until blue diode on LED quickly flashes continuously. At this time, the transmitter enters pairing mode. Transmitter will automatically search for Bluetooth stereo receiver and get connected.

6. Receiving mode

Pairing with Bluetooth devices

To enter pairing mode, put 3.5mm plug in pink 3.5mm port on the adapter. Press and hold multifunction button for about 4-5 seconds, and do not release it until red and blue LEDs flashes alternately

Note: The pairing mode will last 2 minutes. The receiver will automatically switch to standby mode if no devices can be connected within 2 minutes.

Please make sure your smartphone/tablet is Bluetooth-enabled. Specific pairing steps may vary with different models. Please refer to your smartphone/tablet user's manual for further information. The general pairing steps are as follows:

- 1) Activate Bluetooth function and enter the smartphone/tablet pairing mode. Search for Bluetooth devices within range. After the search is completed, select TR01 from the list of devices shown;
- 2) According to the indication, enter password or PIN No: "0000";
- 3) If prompted by your cell phone to connect, select "Yes";
- 4) After successful connecting, blue LED of the receiver will flash every few seconds.

7. Status LED

ON	Blue LED flashes every half second
OFF	Blue LED is off
Charging	While charging red LED is on. After the adapter is charged it goes out.
Receiver mode	Blue receiver LED is on
Low battery	Red LED flashes every half second
Waiting for connection	Blue Bluetooth LED flashes every half second
Connected	Constant blue LED
Transmitting mode	Red transmitting LED is on
Searching for Bluetooth devices	Blue Bluetooth LED flashes every few seconds

Battery operation and maintenance:

- a) batteries should not be exposed to extremely low (below 0 ° C) and high temperatures (above + 35 ° C).
- b) battery life is dependant on ambient temperature, humidity and the intensity of the device use.
- c) do not leave the battery completely discharged.
- d) mechanically damaged batteries are not suitable for use.
- e) when charging is complete the battery should be disconnected from power source immediately.
- f) you can find detailed information on battery operation on our website www.arkas.pl